

Model Railway Radio Control

Thank you for requesting a Micron R/C Model Rail catalog. These pages have been printed off the Micron web site (www.micronradiocontrol.co.uk) where much more information is available.

We are proud to stock a full-range of the Deltang 2.4GHz DSM2/DSMX receivers many of which are optimised for R/C Model Rail. A brief overview is printed below - please don't hesitate to contact us if you want more information or which to discuss a specific installation.

Regards

--

Andy Rutter

Contact:

Address: Micron R/C, Uplands House, Castle Howard Road, Malton, YO17 6NJ

Email: info@micronradiocontrol.co.uk

Telephone: 01653 696008


Email is the best contact method as it is not always possible to answer the telephone. If you do call and get the answer service, please leave a message with name and telephone number and we will return your call as soon as possible.

Eliminate worry about dirty track, stalls, shorts and all the frustrations of track power. Battery power and radio control – the future of model railways.

Radio control (R/C) operation of model railways offers considerable advantages over conventional methods, either direct voltage control or DCC. Like DCC, each R/C model is controlled from within the model itself, so there are no problems running more than one train on a track. But, R/C allows battery operation eliminating any worries about dirty tracks, getting stuck on insulated turnout frogs, etc. R/C trains can operate alongside track powered locos, either direct control or DCC.

There is no need to section the track, R/C provides true 'cab control' so you always have full control over your train. Some R/C controllers can handle up to 12 locos, switching 'active' control between each of them. Non-active locos can be configured to either continue at the last setting or stop.

Compared to the complexity involved in trying to achieve the same level of operation from conventional wiring, the installation of a R/C battery operated locomotive is relatively simple. The on-board components consist of a radio receiver, usually with built-in speed controller, batteries and motor connected as shown on the right. A switch is needed to isolate the battery when the loco is not in use and some method of connecting to a charger is also required - both can be achieved simply with micro plugs/sockets. A fuse in the battery positive lead is recommended to protect the battery in case of inadvertent shorts while working on the loco.



The simplest way of getting started is to choose a receiver with lead-out wires for motor and battery: the red and black wires go to the battery and the yellow or white wires go to the motor. Our range of receivers covers all scales and gauges; from N to SM32, Gauge 1 and beyond with motor currents from 0.5A to 6A. If your motor needs more than 6A, a receiver and separate speed controller can be used.



Although most ready-to-run locos have 12V motors to suit powered rail layouts, many trains do not need this voltage. Slow speed operation (e.g narrow gauge and shunting) works well with 6V or less; even main-line locos rarely use more than 9V. These voltages are easily provided from [single \(3.7V\)](#) or [double cell \(7.4V\)](#) Lithium Polymer batteries. Multiple cell LiPo batteries require a balancing charger and multi-wire charge lead (e.g. 4 wires for a 3 cell battery). A simpler solution for > 4V, easier to install and charge, is to use a single cell LiPo with a [voltage booster](#) module.

Receiver Options

[Rx41d](#), Tiny receivers for N gauge, 009, small OO/HO locos. Max 6V and 0.5A motor current.

[Rx45](#)

[Rx63](#) Smallest 'high' voltage receiver, up to 9V and 0.5A (1A at 5V), suitable for OO/HO, 0n30.

[Rx60](#), 13V receivers, up to 1.3A motor current, slightly larger than Rx63.

[Rx61](#)

[Rx65](#) 13V, 3A receiver, suitable for larger locos (e.g. O Gauge, SM32)

[Rx66](#) 18V, 4A receiver, 6A with optional heatsink

[Rx102](#) 5 servo and 2 on/off outputs (e.g. for lighting) but no built-in speed controller. Use with servos for live steam or a [high current ESC](#) for > 6A

The receivers have short wire aerials. Some are also available with an extended aerial for use in totally enclosed metal bodied locos. All receivers have multiple auxiliary outputs for controlling lights, coupling actuators, sound modules or whatever on-board function your imagination wants to implement.

All Deltang receivers contain extensive programmable features so that you can implement exactly the model control you need. Each receiver is available with several 'variants' which provide a selection of the programmable features appropriate for a typical use. For example: the '-2' variant is for model rail use with a single loco controller such as the [Tx20](#) or [Tx21](#) and the '-22' variant is for use with a multi-loco controller such as the [Tx22](#).

When selecting a receiver you must ensure that:

- the battery voltage when fully charged does not exceed the maximum allowed for the chosen receiver - [Rx4x](#) receivers have a maximum working voltage of 6V; [Rx6x](#) can operate on 13V (18V for the [Rx66](#))
- the motor current when stalled must not exceed the maximum allowed for the chosen receiver - see the receiver specification; completely enclosing the receiver (e.g. in foam) will reduce the current capacity, it is always a good idea to allow for air circulation

When installing a miniature receiver in your model, you must ensure that no force or stress is applied to the circuit board. Miniaturisation requires thin materials which must naturally be handled gently. Most of the receivers are supplied as bare boards and care must be taken to avoid shorting the circuit board tracks. A heat shrink sleeve cover will provide protection and this is available as a no-cost option on many of the receivers we stock. Also, the motor output must not be shorted.

Receiver Outputs

All receivers have several auxiliary outputs in addition to the motor controller. These can be used for controlling lights, sound cards, smoke generators, couplers, etc. Use of these outputs is highly variable as it depends on what additional behaviour you want to build into your model. Please [contact Micron](#) if you want to discuss the options.

Deltang receiver outputs are labelled 'H', 'P' and 'F' to denote their capability:

H H-Bridge Reversible Speed Controller

Most Deltang model rail receivers have at least one reversible speed controller - the exception is [Rx102](#) which is for live steam or, with an external ESC, (very) large scale locos. Some receivers have more than one speed controller: [Rx47](#) [Rx65](#) (with daughter board)

P low-current voltage source

This is a direct connection to the receiver microprocessor: off is 0V and on is 3.3V. It is commonly used for switching LEDs for lighting. The maximum current is limited by the CPU capability: 8mA for most [Rx4x](#) and 20mA for [Rx47](#) and [Rx6x](#). With care, a P output may be used to control external circuits (e.g. sound module) with higher voltages by switching to ground via a series 4k7 ohm

resistor (the max current still applies)

F high-current switch

This is a FET switch with an open-drain which allows it to control high voltage (> 3.3V) external circuits with up to 2A current. When the switch is off, the output pad floats (not connected to either negative or positive); when on, the output is connected to negative. If a receiver has no F outputs (or not enough) but you need to switch a load current greater than 20mA (or 8mA for Rx4x receivers), an external [FET switch](#) can be used to convert a P to a F.

Transmitters / Controllers

We have a range of compatible hand-held transmitter controllers from simple, single loco to multi-train units. All are pocket sized and available with forward / reverse on one knob or full-range throttle and separate direction control. We can also build bespoke controllers with knobs, switches, push buttons to match your needs.

Many transmitters can be used simultaneously without frequency control or crystals. For this to work, every receiver needs to be paired with one transmitter in a process called binding. During binding, the transmitter's unique ID (GUID) is given to the receiver. The receiver then only obeys that transmitter. A receiver needs binding only once. When the receiver is switched on, it searches for its bound transmitter - which is why the transmitter should be switched on first.

The transmitter can share its GUID with any number of receivers. One transmitter can control any number of locomotives, but they all receive the same signals so you normally only have one loco switched on at a time. Some of the Deltang transmitters have the 'Selecta' feature which is used to select a loco to control. When used with a Selecta enabled receiver (variant -22), the position of the Selecta switch is stored by the receiver during bind. This allows up to 12 locos to be switched on at the same time and the Selecta switch controls which loco is currently active. The Selecta feature is supported in most receivers, but must be enabled before use.

The Deltang controllers and receivers operate on 2.4GHz using the popular Spektrum DSM2 protocol. This means that they are compatible with a wide range of other R/C equipment.

Tx20 A simple, single loco controller with large knob for throttle control, a centre-sprung 3-way switch that can be used for direction control or for lighting, sound, etc. and 2 push buttons that can be used to actuate any of the receiver auxiliary outputs.

Tx22v2 A controller for up to 12 locos using the 'Selecta' system. Receivers respond to commands to enable and disable control - a 'disabled' receiver can be configured to stop the motor or continue at the current setting. The Rx6 and Rx47 receivers can also be configured to allow transfer of control across hand-sets - a sort of 'cab control'.

The **Tx21** and **Tx22v2** transmitters have an 'inertia' control which sets the loco acceleration and deceleration behaviour. Inertia is implemented in the transmitter to ensure compatibility with all model rail receivers (including non-Deltang receivers). **Rx6x** receivers also have a built-in inertia function which may be enabled by programming the receiver.

Batteries

Whilst it is possible to run locos with non rechargeable batteries, it is more economical to use rechargeable batteries. On-board batteries can be NiMH, LiIon or LiPo. LiPo and LiPo provide the best size/capacity ratio and ease of installation. All batteries need careful handling, shorting any type will result in lots of heat and you MUST use a resettable fuse in the positive lead as close as possible to the battery - definitely before the on/off switch and charge socket. This is to protect your model in the event of a wiring fault.

When selecting a battery for your loco, you need to look for the highest capacity that will fit into the available space as this will give the longest run-time before needing a charge. If shape of the internal space will not allow for a multi-cell battery, separate cells with interconnecting wires can be used.

Batteries can be charged in the model and LiIon/LiPo can be frequently topped up when the loco is resting. NiMH is best run until discharged and then fully charged to avoid voltage depletion (aka



'memory effect'). Most locos do not need the full 12V - 4V or 8V from 1 or 2 LiPo cells is usually sufficient. LiPo cells come in a wide range of shapes and sizes making it easy to fit into your loco, tender or wagon.

Installation

First choose the components:

- single loco or multi-loco (Selecta enabled) transmitter
- receiver to suit the loco working voltage and motor stall current
- battery voltage to suit the loco operating style and capacity/size to fit the available internal space
 - 12V for 0 Gauge and smaller, 8V-9V is often sufficient for shunting locos
 - single LiPo cell and voltage booster for locos with restricted space
 - 15V-16V for G Scale and Gauge 1
- wiring harness: on/off switch, charge socket and resettable to protect the battery fuse - Micron has a selection of [switch modules](#) which comprise a switch, Molex charge socket and a LED to repeat the receiver on-board LED

Plan the installation:

- choose location for receiver, battery (or LiPo cell plus voltage booster), on/off switch and charge socket
- if a steam loco, an ideal place for the on/off switch is under a removable dummy coal load
- determine wire lengths between components, route to avoid moving parts

If the loco has a DCC socket, the actual installation can be easy as the receiver motor output to the DCC socket motor pins. Otherwise:

- disconnect the wheel pickups from the motor
- fix the battery in place - protect from movement and any sharp edges if a metal bodied loco
- fix the receiver in place - a piece of double sided foam tape (aka servo tape) is usually sufficient
- fix the on/off switch and charge socket in place
- complete the wiring:
 - battery to on/off switch, with resettable fuse in battery positive lead
 - on/off switch to receiver
 - receiver motor output to motor

You can either wire all components together permanently or use connectors to allow easy separation of the body from the chassis. Miniature [1.27mm pitch](#) polarised and non-polarised connectors are good for the smaller scales (N, OO, 009) and [Molex 2mm pitch](#) connectors are appropriate for O Gauge, SMT32, Gauge 1, etc.

More complex installations add lighting, sound, smoke control, couplers, ... The Deltang range of receivers is capable of handling it all.

We provide an [installation service](#) if you don't feel up to doing it yourself. [Contact us](#) for details.

© Micron Radio Control